


WT Ozone Well Water System

Water Sources

1. Well
2. Surface water
3. Water Re-use



Water Connections 1" NPT

1. Raw Water IN
2. Water TO Filter – plugged if no filter is needed
3. Water FROM Filter – plugged if no filter is needed
4. Treated water OUT

Hard Plumb, or use 1" FIP stainless flexible connections. Connections to and from Filter #2 and #3 must be 1". Connections #1 and #4 can be sized to match existing plumbing.



Filtration Options:

- 1) FIOX or comparable backwashable filter – removes oxidized iron or manganese particles. Also serves to protect the pump and venturi from iron and manganese deposits.
- 2) Activated Carbon – removes finer particles, and also removes ozone.

